



## System Requirements

These configuration tools are designed for Microsoft Windows XP, 2000 and NT. Minimum hardware requirements are:

- 100 MHz or faster Pentium PC
- 128 MB RAM
- CD-ROM drive
- 100 MB available hard drive space
- Available RS-232 serial port and null modem cable
- Ethernet port with RJ45 crossover cable for direct connection to module

*or*

Ethernet hub with standard RJ45 Ethernet cable

## Additional Products

ProSoft Technology offers a full complement of hardware and software solutions for a wide variety of industrial communication platforms.

Visit our web site at <http://www.prosoft-technology.com> for a complete list of products.

---

## Ordering Information

To place an order, please contact your local ProSoft Technology distributor. For a list of ProSoft distributors near you, go to <http://www.prosoft-technology.com>

### Distributors:

Place your order by email or fax to:

#### **North American / Latin American / Asia Pacific**

[orders@prosoft-technology.com](mailto:orders@prosoft-technology.com),

fax to +1 661.716.5101

#### **Europe**

[europe@prosoft-technology.com](mailto:europe@prosoft-technology.com),

fax to +33 (0) 5.34.60.59.74