

# Legacy Product Replacement

**The move to new products will help you gain greater functionality!**

ProSoft Technology commits to quality, performance, and transparency for our valued customers. As our products age and as we continue to innovate, ProSoft works to provide you with enough advanced notice and support to allow you to make business decisions regarding your migration or enhancement strategies.

Below is ProSoft's directory of products that are being phased out and their replacement solutions. The move to new products is designed to be seamless, and will help you gain greater functionality in most cases. Need clarification when selecting or setting up your replacement solution? ProSoft's technical support team is always available to guide you through your smooth transition.

| Legacy Product                   | Replacement                     | How You'll Benefit                            |
|----------------------------------|---------------------------------|---|
| <a href="#">3170-PDP</a>         | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5102-DNPM-MCM3</a>   | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5102-DNPS-DFCM3</a>  | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5102-MCM-ASCII3</a>  | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5104-MCM-PDPMV1</a>  | <a href="#">PLX51-PBM</a>       | <a href="#">Contact our Technical Support</a> |
| <a href="#">5105-101S-PDPS</a>   | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5105-ASCII-PDPS</a>  | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5105-DFCM-PDPS</a>   | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5105-DNPM-PDPS</a>   | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5105-MCM-PDPS</a>    | <a href="#">PLX51-PBS</a>       | <a href="#">Contact our Technical Support</a> |
| <a href="#">5107-MCM-HART</a>    | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-104S-103M</a>   | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-104S-DFCM</a>   | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-104S-MCM</a>    | N/A                             | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-DFNT-104S</a>   | <a href="#">PLX32-EIP-104</a>   | <a href="#">Read the Technical Note</a>       |
| <a href="#">5201-DFNT-ASCII</a>  | <a href="#">PLX31-EIP-ASCII</a> | <a href="#">Read the Technical Note</a>       |
| <a href="#">5201-DFNT-BACNET</a> | <a href="#">PS-QS-1X10-0780</a> | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-DFNT-DFCM</a>   | <a href="#">PLX51-DF1-ENI</a>   | <a href="#">Read the Technical Note</a>       |

| Legacy Product                     | Replacement                      | How You'll Benefit                            |
|------------------------------------|----------------------------------|---|
| <a href="#">5201-DFNT-DH485</a>    | <a href="#">DH485 Router</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-DFNT-DNPM</a>     | <a href="#">PLX51-DNPM</a>       | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-DFNT-DNPS</a>     | <a href="#">PLX51-DNPS</a>       | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-DFNT-DNPSNET</a>  | <a href="#">PLX51-DNPS</a>       | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-DFNT-GRCM</a>     | N/A                              | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-DFNT-MCM</a>      | <a href="#">PLX31-EIP-MBS</a>    | <a href="#">Read the Technical Note</a>       |
| <a href="#">5201-DNPSNET-MCM</a>   | N/A                              | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-MNET-101S</a>     | N/A                              | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-MNET-103M</a>     | N/A                              | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-MNET-BACNET</a>   | <a href="#">PS-QS-1X10-0757</a>  | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-MNET-BSCH</a>     | N/A                              | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-MNET-DFNT</a>     | <a href="#">PLX31-EIP-MBTCP</a>  | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-MNET-DNPM</a>     | <a href="#">PLX51-DNPM</a>       | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-MNET-DNPS</a>     | <a href="#">PLX51-DNPS</a>       | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-MNET-DNPSNET</a>  | <a href="#">PLX51-DNPS</a>       | <a href="#">Contact our Technical Support</a> |
| <a href="#">5201-MNET-MCM</a>      | <a href="#">PLX31-MBTCP-MBS</a>  | <a href="#">Contact our Technical Support</a> |
| <a href="#">5202-DFNT-ASCII4</a>   | <a href="#">PLX31-EIP-ASCII4</a> | <a href="#">Read the Technical Note</a>       |
| <a href="#">5202-DFNT-DFCM4</a>    | N/A                              | <a href="#">Contact our Technical Support</a> |
| <a href="#">5202-DFNT-MCM4</a>     | <a href="#">PLX31-EIP-MBS4</a>   | <a href="#">Read the Technical Note</a>       |
| <a href="#">5202-MNET-ADM4</a>     | N/A                              | <a href="#">Contact our Technical Support</a> |
| <a href="#">5202-MNET-DFCM4</a>    | N/A                              | <a href="#">Contact our Technical Support</a> |
| <a href="#">5202-MNET-MCM4</a>     | <a href="#">PLX31-MBTCP-MBS4</a> | <a href="#">Contact our Technical Support</a> |
| <a href="#">5204-DFNT-PDPMV1</a>   | <a href="#">PLX51-PBM</a>        | <a href="#">Contact our Technical Support</a> |
| <a href="#">5204-MNET-PDPMV1</a>   | <a href="#">PLX51-PBM</a>        | <a href="#">Contact our Technical Support</a> |
| <a href="#">5204SE-MNET-PDPMV1</a> | <a href="#">PLX51-PBM</a>        | <a href="#">Contact our Technical Support</a> |
| <a href="#">5205-104S-PDPS</a>     | N/A                              | <a href="#">Contact our Technical Support</a> |
| <a href="#">5205-BACNET-PDPS</a>   | N/A                              | <a href="#">Contact our Technical Support</a> |

| Legacy Product                   | Replacement                   | How You'll Benefit                            |
|----------------------------------|-------------------------------|---|
| <a href="#">5205-DFNT-PDPS</a>   | <a href="#">PLX51-PBS</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">5205-MNET-PDPS</a>   | <a href="#">PLX51-PBS</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">5207-DFNT-HART</a>   | <a href="#">PLX51-HART-4I</a> | <a href="#">Read the Technical Note</a>       |
| <a href="#">5207-MNET-HART</a>   | <a href="#">PLX51-HART-4I</a> | <a href="#">Read the Technical Note</a>       |
| <a href="#">5208-DFNT-HART</a>   | <a href="#">PLX51-HART-4I</a> | <a href="#">Read the Technical Note</a>       |
| <a href="#">5208-MNET-HART</a>   | <a href="#">PLX51-HART-4I</a> | <a href="#">Read the Technical Note</a>       |
| <a href="#">5209-DFNT-CCLINK</a> | N/A                           | <a href="#">Contact our Technical Support</a> |
| <a href="#">5228-DFNT-HART</a>   | <a href="#">PLX51-HART-4I</a> | <a href="#">Read the Technical Note</a>       |
| <a href="#">5228-MNET-HART</a>   | <a href="#">PLX51-HART-4I</a> | <a href="#">Read the Technical Note</a>       |
| <a href="#">5507-PDPS-HART</a>   | N/A                           | <a href="#">Contact our Technical Support</a> |

| Legacy Product                | Replacement                     | How You'll Benefit  |
|-------------------------------|---------------------------------|---|
| <a href="#">MVI46-GSC</a>     | <a href="#">PLX31-EIP-ASCII</a> | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI46-MCM</a>     | <a href="#">PLX31-EIP-MBS4</a>  | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI46-MNET</a>    | <a href="#">PLX31-EIP-MBTCP</a> | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI46-MNETC</a>   | <a href="#">PLX31-EIP-MBTCP</a> | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI46-PDPS</a>    | N/A                             | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI46-PDPMV1</a>  | N/A                             | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI56-ADM</a>     | <a href="#">MVI56E-LDM</a>      | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI56-ADMNET</a>  | <a href="#">MVI56E-LDM</a>      | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI56-AFC</a>     | <a href="#">MVI56E-AFC</a>      | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI56-DFCM</a>    | <a href="#">PLX51-DF1-ENI</a>   | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI56-DFCMR</a>   | <a href="#">PLX51-DF1-ENI</a>   | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI56-DNPSNET</a> | <a href="#">MVI56E-DNPNET</a>   | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI56-GEC</a>     | <a href="#">MVI56E-GEC</a>      | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI56-GSC</a>     | <a href="#">MVI56E-GSC</a>      | <a href="#">Top Benefits of the Newer Modbus® Modules</a> |
| <a href="#">MVI56-HART</a>    | <a href="#">PLX51-HART-4I</a>   | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI56-MCM</a>     | <a href="#">MVI56E-MCM</a>      | <a href="#">Top Benefits of the Newer Modbus® Modules</a> |

| Legacy Product                | Replacement                     | How You'll Benefit  |
|-------------------------------|---------------------------------|---|
| <a href="#">MVI56-MCMR</a>    | <a href="#">MVI56E-MCMR</a>     | <a href="#">Top Benefits of the Newer Modbus® Modules</a> |
| <a href="#">MVI56-MNET</a>    | <a href="#">MVI56E-MNET</a>     | <a href="#">Top Benefits of the Newer Modbus® Modules</a> |
| <a href="#">MVI56-MNETC</a>   | <a href="#">MVI56E-MNETC</a>    | <a href="#">Top Benefits of the Newer Modbus® Modules</a> |
| <a href="#">MVI56-MNETCR</a>  | <a href="#">MVI56E-MNETCR</a>   | <a href="#">Top Benefits of the Newer Modbus® Modules</a> |
| <a href="#">MVI56-MNETR</a>   | <a href="#">MVI56E-MNETR</a>    | <a href="#">Top Benefits of the Newer Modbus® Modules</a> |
| <a href="#">MVI56-PDPMV1</a>  | <a href="#">ILX56-PBM</a>       | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI56-PDPS</a>    | <a href="#">ILX56-PBS</a>       | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI56-SMGC</a>    | <a href="#">MVI56E-SMGC</a>     | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI69-104S</a>    | <a href="#">PLX32-EIP-104</a>   | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI69-ADM</a>     | <a href="#">MVI69E-LDM</a>      | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI69-ADMNET</a>  | <a href="#">MVI69E-LDM</a>      | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI69-AFC</a>     | <a href="#">MVI69E-AFC</a>      | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI69-DFCM</a>    | <a href="#">PLX51-DF1-ENI</a>   | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI69-DNP</a>     | <a href="#">PLX51-DNPx</a>      | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI69-DNPSNET</a> | <a href="#">PLX51-DNPx</a>      | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI69-GEC</a>     | <a href="#">MVI69E-GEC</a>      | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI69-GSC</a>     | <a href="#">MVI69E-GSC</a>      | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI69-HART</a>    | <a href="#">PLX51-HART-4I</a>   | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI69-MCM</a>     | <a href="#">MVI69E-MBS</a>      | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI69-MNET</a>    | <a href="#">MVI69E-MBTCP</a>    | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI69-MNETC</a>   | <a href="#">MVI69E-MBTCP</a>    | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI69-PDPMV1</a>  | <a href="#">ILX69-PBM</a>       | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI69-PDPS</a>    | <a href="#">ILX69-PBS</a>       | <a href="#">Read the Technical Note</a>                   |
| <a href="#">MVI94-ADM</a>     | N/A                             | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI94-AT</a>      | N/A                             | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI94-DNP</a>     | N/A                             | <a href="#">Contact our Technical Support</a>             |
| <a href="#">MVI94-GSC-E</a>   | <a href="#">PLX31-EIP-ASCII</a> | <a href="#">Contact our Technical Support</a>             |

| Legacy Product                | Replacement                   | How You'll Benefit                            |
|-------------------------------|-------------------------------|---|
| <a href="#">MVI94-MCM</a>     | <a href="#">PLX31-EIP-MBS</a> | <a href="#">Contact our Technical Support</a> |
| <a href="#">MVI94-MCM-MHI</a> | N/A                           | <a href="#">Contact our Technical Support</a> |

| Legacy Product                   | Replacement                      | How You'll Benefit                            |
|----------------------------------|----------------------------------|---|
| <a href="#">PLX81-EIP-61850</a>  | <a href="#">PLX82-EIP-61850</a>  | <a href="#">Read the Technical Note</a>       |
| <a href="#">PLX81-MNET-61850</a> | <a href="#">PLX82-MNET-61850</a> | <a href="#">Read the Technical Note</a>       |
| <a href="#">PS-QS-1010-0117</a>  | <a href="#">PS-QS-2010-F</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">PS-QS-1010-0757</a>  | <a href="#">PS-QS-2010-F</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">PS-QS-1010-0780</a>  | <a href="#">PS-QS-2010-F</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">PS-QS-1010-0782</a>  | <a href="#">PS-QS-2010-F</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">PS-QS-1510-0117</a>  | <a href="#">PS-QS-2210-F</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">PS-QS-1510-0757</a>  | <a href="#">PS-QS-2210-F</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">PS-QS-1510-0780</a>  | <a href="#">PS-QS-2210-F</a>     | <a href="#">Contact our Technical Support</a> |
| <a href="#">PS-QS-1510-0782</a>  | <a href="#">PS-QS-2210-F</a>     | <a href="#">Contact our Technical Support</a> |